
Assignment - 03

• FTP Server Configuration:

Steps:

- 1) Open Cisco Packet Tracer and select 2 End Devices (PC device), 1 Switch, 1 Router, 1 Server.
- 2) Now Connect all the devices using the auto connection.
- 3) Then configure the IP addresses as per the diagram.






- 4) Now just wait for some time to let all the connection status turns green.
- 5) Now we have achieved a connection where a class C IP address is being translated to class A IP Address.
- 6) Go to one of the PC devices and on Desktop tab select CMD.
- 7) Now we need to check the connection to the server by C:\>ping 10.10.10.2
- 8) If reply is coming then it means the server is properly configured and connected.
- 9) Go to the Server \rightarrow Services \rightarrow FTP.
- 10) Put on the FTP service and give username and password and click on ADD.
- 11) Come back to PC device and open the CMD and type C:\>ftp 10.10.10.2
- 12) It will ask for username and password. Provide the username and password configured earlier.
- 13) Once the connection is established exit rom the CMD and go to Text Editor and make a new text file.
- 14) Save the new text file and return to cmd and type ftp>put filenme.txt
- 15) This will send the text file from the PC device (192.168.0.2) to Server (10.10.10.2).
- 16) Now to verify that the file has been transferred to the server, so type ftp>dir
- 17) You will see your Filename in the list.
- 18) Now to get a file from server to PC type ftp>get filename.txt
- 19) Now exit from FTP type ctrl+C, then type dir to check that the file is there in the PC or not.
- 20) So we have successfully send and got a file from a server using FTP protocol.

• DHCP Server Configuration:

- 1) Open Cisco Packet Tracer and select 2 End Devices (PC device), 1 Switch, 1 Router, 1 Server.
- 2) Now Connect all the devices using the auto connection.
- 3) Then configure the IP addresses as per the diagram.





- 4) Now just wait for some time to let all the connection status turns green.
- 5) Now go to the server \rightarrow Desktop \rightarrow IP Configuration and set the IP 192.168.0.1.
- 6) Go to Services → DHCP and set Default Gateway 192.168.0.1 and DNS Server 10.0.0.1.
- 7) Set the Start IP 192.168.0.0 and Max Users 256
- 8) Now go to every PC device \rightarrow Desktop \rightarrow IP Configuration and set it to DHCP.
- 9) Now all the PC will have a DHCP address.